



## How Do I ..... install PC99-JVC

The following guide shows step by step guide to installing PC99-JVC

### Compatibility.

JVC head units must be specified as Steering Remote control Ready and feature a 3,5mm Stereo head phone type socket on the back of the unit. Later Models feature a single wire marked "steering remote" There is also a procedure for installing these leads to ensure it recognises the remote controls, see Installation Tip below. None of the PC99-X\*\* leads will interface with the cars display. When using the new PC99 X\*\* range of car steering interface leads, you will also require PC99-JVC to interface with the head unit.

### Installation Tip.

For the PC99 range of Steering control leads, we offer the dedicated head unit adaptors such as PC99-JVC. These have to be installed in a set order to ensure the head unit recognises the new leads are attached. Please follow this routine when installing PC99 leads.

1. Make sure the two orange wires on the JVC link are not connected to each other or anything else. These remain disconnected even when installation complete.  
(Same part as PC99-ALP where they are connected for use with Alpine).
2. Link the JVC interface to the PC99-X## series lead.
3. Plug the main loom (not the jack) into both the vehicle and the head unit.
4. Power up the stereo by ignition and seek then store a radio station (this wakes the unit up)
5. Switch the stereo off by ignition.
6. Plug in the jack on the back of the stereo, or the single wire marked "Steering Remote"
7. Switch the stereo on by ignition and wait up to 20 minutes for Audio to come through before testing the remote controls.
8. If in any doubt that this has not been done in the correct order, the loom must be disconnected from the vehicle, the jack disconnected from the stereo and the process started again.

This system seems to be needed on new (2005) Sony's, JVC's and Alpines. Due to the higher technology employed in these units, they operate more like computers then audio systems, so the addition equipment such as CD Changers, Auxilliary inputs and Steering remote control devices, need to be 'found' by the system after it has been awoken as just a stereo. Future instructions supplied with the leads will cover this.

For more information, please e-mail [Technical@nexxia.co.uk](mailto:Technical@nexxia.co.uk)